



INDIA'S BEST QUALITY
Alap and Milap
AGRICULTURE EQUIPMENTS

CHAFF CUTTER SPARE PARTS NAME LIST

Every part on the ALAP chaff cutter (kutti machine) - what it does, what it is called at the parts counter, and the sign that tells you it needs replacing. With a labelled diagram.

Chaff cutter · kutti machine

WHAT IS INSIDE

02 Labelled chaff cutter diagram - match each number to the part

03 Parts list - 10 parts, what each does and when to replace

03 Keep these in the shed, and how to order

Almighty Agrotech Pvt. Ltd.


manufacturing ALAP and MILAP farm machinery since 1977

Kalawad Road, Metoda, Rajkot, Gujarat 360021 · +91 99792 55149 · almightyagro.com

THE PARTS YOU CAN POINT AT

SIDE VIEW

A chaff cutter feeds fodder between two rollers onto a fixed plate, where blades on a spinning flywheel slice it short, driven by a belt from the motor. Match each number to the part list below.



#	PART NAME	WHAT IT DOES	REPLACE WHEN
1	Cutting blades (flywheel blades)	Slice the fodder into short pieces	Edges dull or chipped, fodder tears instead of cutting
2	Shear plate (fixed plate)	The blades cut against it	Grooved or worn, cut pieces come out uneven
3	Upper and lower feed rollers	Grip and pull the fodder into the blades	Teeth worn smooth, fodder slips or feeds unevenly
4	Roller gears	Drive the feed rollers in time	Teeth chipped, rollers jerk or stop
5	Flywheel	Carries the blades and keeps momentum	Cracks or heavy imbalance, inspect yearly
6	Main shaft	Holds the flywheel and spins it	Bent, machine vibrates badly
7	Bearings	Let the shafts spin smoothly	Noisy, hot or loose, play in the shaft
8	V-belt and pulley	Carry power from the motor or engine	Belt cracked, glazed or slipping under load
9	Blade bolts and nuts	Hold the blades to the flywheel	Stretched, worn or coming loose
10	Feed tray and safety guard	Where you load fodder, and the flywheel cover	Cracked, bent, or guard missing

KEEP THESE IN THE SHED

BEFORE THE SEASON

The same short list accounts for most of the downtime on a chaff cutter. Stock these before the season, not after the machine stops in the middle of it.

1

Cutting blades

2

Shear plate

3

V-belt and pulley

4

Bearings

5

Feed rollers

6

Blade bolts and R pins

HOW TO ORDER THE RIGHT PART

1. Find the chaff cutter model on the machine plate (for example the ALAP AC-9Z-1.0).
2. Pick the part name from the list on page 02, and note how many blades you need.
3. Say whether the part is a flywheel or a plate part, so you get the right one.
4. For blades, bearings and belts, confirm the size for your model before ordering.

NOT SURE WHICH PART YOU NEED?

Send us your model number and what the machine is doing wrong. Our team will tell you which part it is and which dealer near you stocks it.

CALL

+91 99792 55149

EMAIL

aap@almightyagro.com

ONLINE

almightyagro.com/products/spare-parts